


Fendequip


Titanium Pillar Fender - Installation Instructions




Remove pillar fender from storage bag - place onto a stable surface




Inflate fender to working pressure (approx 1psi)




Raise fender into upright position (using integrated grab handles)




Turn 180 degrees - with foot facing outboard




Move to edge of platform (can balance via the inflatable fender)



Gently lower towards the water (with inflatable fender facing inboard)



Carefully turn 180 degrees - before locating into deck positions



Secure into place - with supplied fitting pins