

Fendequip

Titanium Pillar Fender Installation Instructions

1.

**Remove pillar fender
from storage bag** – place
onto a stable surface




Fendequip

Titanium Pillar Fender Installation Instructions

2.

**Inflate fender to working
pressue** (approx $\leq$ 1psi)




Fendequip

Titanium Pillar Fender Installation Instructions

3.

Raise fender into upright position (using integrated grab handles)





Fendequip

Titanium Pillar Fender Installation Instructions

4.

Turn 180 degrees – with
foot facing outboard




Fendequip

Titanium Pillar Fender Installation Instructions

5.

Move to edge of platform
(can balance via the
inflatable fender)




Fendequip

Titanium Pillar Fender Installation Instructions

6.

**Gently lower towards
the water** (with inflatable
fender facing inboard)




Fendequip

Titanium Pillar Fender Installation Instructions

7.

Carefully turn 180 degrees – before locating into deck positions



Fendequip

Titanium Pillar Fender Installation Instructions

8.

Secure into place – with
the supplied fitting pins

